

# Assembly Instructions

## Express Laundry Hamper

- Before you begin to assemble your new piece of furniture, please check to ensure that all parts have been supplied.
- Follow instructions closely as deviation from them may void your warranty and present a possible safety risk.
- It is recommended that assembly is done on a soft surface like carpet to avoid any damage.
- If you experience any problems with your new purchase please phone Freedom Customer Service (FCS) on 1300 135 588 (Customers outside Australia should contact their closest Freedom store.)

### Care Information:

Periodically check and re-tighten all fasteners. Wipe down surfaces using a clean cloth weekly. Avoid direct sunlight.

### Hardware



□ A x 8 □



□ B x 4 □



□ C x 4 □



□ J x 1 □

### Parts




□ D x 1 □



□ E x 2 □



□ F x 4 □




□ G x 1 □




□ I x 2 □

### Step 1.




### Step 2.



# Assembly Instructions

## Express Laundry Hamper

Step 3.



Finished.

