

TORQUAY COFFEE TABLE 110x65CM WHITE

23455597

Outdoor



Thank you for purchasing the Torquay Coffee Table 110x65cm White . Before you begin to assemble your new piece of furniture, please check to ensure that all hardware and parts have been supplied. This page lists all contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.

It is recommended that assembly is done on a soft surface such as carpet to avoid any damage.

If you experience any problems with your new purchase, please phone Freedom Customer Service (FCS) on 1300 135 588 (Australia) or 0800 469 327 (New Zealand).


Care Information

This product is suitable for Full Outdoor Use

We test all our outdoor ranges to ensure that they're durable and can withstand the elements. With minor care, these items can be left outdoors permanently.

- Furniture made with polyester, man-made wickers and aluminium can be simply washed down with warm soapy water and left to dry naturally. This should be done on a regular basis.
- To prolong lifetime store in a dry location when not in use or during periods of inclement weather.


Hardware (Supplied)




Part A x 4



Part B x 4




Part C x 4




Part D x 1


Parts



Part E x 2




Part F x 1



TORQUAY COFFEE TABLE 110x65CM WHITE

23455597

Step 1.




! Do not lift by table leg, take care when orientating table onto its feet.

TORQUAY COFFEE TABLE 110x65CM WHITE

23455597

Step 2.



TORQUAY COFFEE TABLE 110x65CM WHITE

23455597

Finished.

