


DOME Archway Floor lamp 18762/15 SKU23489394

Before first using your new DOME Archway Floor lamp, it is most important that you read and follow these instructions, even if you feel you are quite familiar with this type of product. Find a place and keep this document handy for future reference.

Assembly instructions:

Follow these instructions closely as deviation may void your warranty and present a possible safety risk.

- 1) Remove the Floor lamp from the packaging and dispose of packaging materials thoughtfully.
- 2) Check all parts have been supplied.
- 3) It is recommended that any assembly is performed on a soft surface to avoid any damage
- 4) Ensure the power is switched off at the wall socket and DO NOT connect at this stage. Screw the upper post 'B' to lower post 'A'.
- 5) Screw the upper post 'B' to lower post 'A' creating the post assembly.
- 6) Screw the bottom section of the suspension arm 'C' to the post assembly.
- 7) Connect the top section of the suspension arm 'D' to the post and lower suspension arm assembly and tighten the 2 grub screws with the Allen key provided.
- 8) Insert the suspension arm assembly and post to the base 'E'. Screw the nut "F" into place firmly. Do not over tighten.
- 9) Carefully pull any excess cord through the exit at the bottom of the post 'A' as the floor lamp is assembled.
- 10) Remove the threaded ring 'G' from the lampholder 'H'.
- 11) Place the dome shade 'J' over the lamp holder 'H' and replace the threaded ring 'G'. Screw the ring on until is firm. Do not over tighten.
- 12) Screw the E27 globe (not included) into the lamp holder ensuring that it is secured firmly. Do not over tighten.
- 13) Plug the cord into the selected wall socket, turn the wall socket on and switch the Floor lamp ON using the switch located on the cord.



SPECIFICATIONS:

Fitting: Archway Floor lamp
Globe: 240V E27 max 70W globe
 or equivalent LED or CFL lamp
Construction: Class II

Indoor Use Only
 Made in China

WARNING:

- This Floor lamp must be connected to a 240V 50Hz power source.
- Don't damage the wiring in process of assembly
- Ensure all parts are firmly connected together
- Ensure that the switch is in the OFF position and/or the plug is removed from the wall socket when changing light globes.
- Light globes are extremely hot when in use. Always remove globes only when they have cooled to room temperature.
- This Floor lamp is not intended for use by children or infirm persons without supervision.
- Young children should be supervised to ensure they DO NOT play with this Floor lamp.
- This Floor lamp is not designed for outdoor use.
- Ensure that the globe is at least 30cm from the nearest object at all times.