

BRANDON Dining table 110 cm

Australia: 23511712, 23511729

New Zealand:

freedom 

Thank you for purchasing the **BRANDON Dining table 110 cm**. Before you begin to assemble your new piece of furniture, please check to ensure that all hardware and parts have been supplied. This page lists a contents included in the carton(s).

Follow instructions closely as deviation from them may present a possible safety risk and may void your warranty.

It is recommended that assembly is done on a soft surface such as carpet to avoid any damage.

If you experience any problems with your new purchase please phone Freedom Customer Service (FCS) on 1300 135 588. Customers outside Australia should contact their closest Freedom store.


Care Information

Periodically check and re-tighten any fasteners. Dust weekly using a soft, clean cloth. Do not use harsh abrasives, chemicals or polishes containing silicone. Avoid direct sunlight as this may cause the timber to change colour. It is important to remove moist substances immediately.

Always carefully lift furniture when moving it around the home and never drag.

Use floor protectors on the bottom of furniture (like tables and chairs) to minimise damage to floor coverings.

Use coasters, place mats, tablecloths and table runners to protect furniture surfaces from heat and stains



BRANDON Dining table 110 cm



Australia: 23511712, 23511729

New Zealand:

freedom 

Parts

PART	QTY	SIZE	CHECK <input checked="" type="checkbox"/>
1	1	1100x1100x19	
2	4	720x48x48	



BRANDON Dining table 110 cm

Australia: 23511712, 23511729

New Zealand:

freedom 

Step 1

